



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

## TA1003 Audi 80 Saloon 92>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	F	2	M10 x 40 Bolts, Nuts & Washers
B	1	Bracing Stay	G	7	M10 x 30 Bolts, Nuts & Washers
C	1	Angle Bracket	H	2	M8 x 35 Bolts, Nuts & Washers
D	1	Clamp Plate	I	2	10 x 30 Flat Washers
E	2	M16 x 50 Bolts, Nuts & Washers	J	3	10 x 50 Flat Washers
			K	2	10 x 25 Flat Washers
			L	2	8 x 25 Flat Washers

1. Remove the rear bumper and spare wheel.
2. Locate the existing holes on the rear panel (these are covered with tape), using Item **G** with Item **K** under each bolt head, and Item **I** inside the boot as a clamping washer; and Item **H** with Item **L** under each bolt head, bolt Item **A** into place, fully tighten these bolts and refit bumper.
3. Using the holes in Item **A** as jigs drill two 11mm holes up into the boot, with Item **D** over the holes inside the boot using Item **F** loosely bolt Item **B** to Item **A**.
4. Using Item **G** bolt Item **C** to Item **B**.
5. Using the holes in Item **C** as jigs drill three 11mm holes into the spare wheel pan, using Item **G** with Item **J** under each bolt head inside the vehicle bolt Item **C** into place.
6. Using Item **E** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

**Note:** nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

