



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

## TA1005 Audi 100/200 '83-'91

Item	Qty	Description	Item	Qty	Description
<b>A</b>	1	Towbar	<b>F</b>	2	M16 x 50 Bolts, Nuts & Washers
<b>B</b>	2	19 x 65 Spacer Tubes	<b>G</b>	4	M12 x 100 Bolts, Nuts & Washers
<b>C</b>	2	19 x 73 Spacer Tubes	<b>H</b>	4	12 x 40 Flat Washers
<b>D</b>	2	65 x 65 Washers			
<b>E</b>	2	50 x 40 Washers			

- 1.** Remove the rear bumper and bumper arms (these are no longer required). Remove grommets from the existing holes above and below the chassis.
- 2.** Cut a slot in the lower edge of the bumper 45mm wide and up to the first change of angle.
- 3.** Bolt the bumper to the towbar using one existing bolt each side.
- 4.** Locate the assembly into the open ends of the chassis.
- 5.** Using item **G** with item **E** inside the boot item **B** up through the existing hole and item **H** on the underside, loosely bolt item **A** into position at the rearmost set of holes.
- 6.** Using item **G** with item **H** inside the boot, item **C** up through the existing slots and item **D** on the underside bolt item **A** to the forward fixings.
- 7.** Using item **F** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
- 8.** Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

**Note:** nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

