



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TYPE: TBM 900 BMW 3 SERIES '83 - '87 & CONVERTABLE '88 -

ITEM	QTY	DESCRIPTION	ITEM	QTY	DESCRIPTION
A	1	Drop Plate	E	2	M16 x 45 Bolts, Nuts & Washers
B	2	Clamp Straps	F	2	M10 x 35 Bolts, Nuts & Washers
C	1	L/H Side Arm	G	10	M10 x 30 Bolts, Nuts & Washers
D	1	R/H Side Arm	H	4	10 x 40 Washers

- 1) Remove the spare wheel.
- 2) Place one of Item B inside the boot and flush against the rear panel with the bottom edge resting on the lip just above the boot floor. Centralise, mark off and drill six 11mm holes through the rear panel.
- 3) Using Item F, loosely bolt Item A and one of Item B to the rear panel with the remaining Item B inside the boot.
- 4) Using Item G, loosely bolt Items C and D to Item A. Spread Items C and D to the outer edges of the spare wheel pan. Using the holes as jigs, drill four 11mm holes up into the boot.
- 5) Using Item G with Item H under each head, bolt Item C and Item D into place.
- 6) Using Item E, bolt the ball bracket and wiring plate (not supplied in this kit) to Item A.
- 7) Fully tighten all nuts and bolts and ensure the towbar is rigid and secure. Replace the spare wheel.

