



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TYPE: TBM 901 BMW 3 SERIES DECEMBER '87 -

ITEM	QTY	DESCRIPTION	ITEM	QTY	DESCRIPTION
A	1	6 Hole Clamp Strap	E	2	M16 x 45 Bolts, Nuts & Washers
B	1	Angle Crossmember	F	2	M10 x 35 Bolts, Nuts & Washers
C	1	Drop Plate	G	10	M10 x 30 Bolts, Nuts & Washers
D	2	Bracing Stays	H	4	10 x 40 Washers

- 1) Remove the rear bumper.
- 2) Place Item A inside the boot against the rear panel with the bottom edge on the floor. Centralise and, using the holes as jigs, drill six 11mm holes through the rear panel.
- 3) Using Item F, loosely bolt Item C and Item B to the rear panel with Item A inside the boot. Using Item G, secure Item B and Item C by the outer holes.
- 4) Using Item G, loosely bolt Items D to Item C. The left hand strap fits outside of the rib. On the right, the forward hole goes through the centre of the rib. Using the holes as jigs, drill four 11mm holes through the spare wheel pan. Using Item G with Item H under the bolt heads, bolt Items D into place.
- 5) Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
- 6) Replace the rear bumper.
- 7) Using Item E, bolt the ball bracket and wiring plate (not supplied in this kit) to the drop plate.

