



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TC609 Citroen ZX Estate 1994 - 1998

Item	Qty	Description	Item	Qty	Description
A	1	Cross Bar	E	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	Extension Bar	F	2	M16 x 35 Bolts, Nuts & S/P Washers
C	2	10 x 50 Washers	G	4	M12 x 35 Bolts, Nuts & S/P Washer
D	4	12 x 40 Washers	H	2	M10 x 30 Bolts, Nuts & S/P Washers
			I	2	Bolt Caps

1. Lower the spare wheel. Remove the rear trim to allow the floor covering to be moved forward.
2. Place Item **A** between the towing eyes.
3. Using Item **G** with Item **D** on the outer face of the towing eyes, loosely bolt Item **A** into place.
4. Using the holes in Item **A** as jigs, drill two 11mm holes up into the floor.
5. Using Item **H** with Item **C** under the bolt heads, bolt Item **A** and fully tighten.
6. Using Item **F**, bolt Item **B** to Item **A**.
7. Using Item **E**, bolt the ball bracket and wiring plate (not supplied in this lit) to the mounting plate.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
9. Replace the spare wheel and floor covering.

Note: nose load limits and vehicle manufacturers' trailer / caravan weight limits must be observed.

