



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

Type TC636 Citroen Xara Hatchback 97> & Coupe 98>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	F	2	M16 x 50 Bolts Nuts & Washers
B	1	Left Hand Side Arm	G	2	M10 x 50 Bolts Nuts & Washers
C	1	Right Hand Side Arm	H	2	M10 x 40 Bolts Nuts & Washers
D	2	Clamp Plates with Bolts	J	5	M10 x 30 Bolts 8 Nuts 9 Washers
E	1	Large Clamp Plate	K	14	10 x 25 Flat Washers

1. Lower the spare wheel, temporarily remove the bolt securing the bumper on the right hand side underneath (the fitter may lower the exhaust at the rear if preferred).
2. Locate item **E** inside the double skin on the underside of the boot floor and using item **J** bolt and fully tighten item **E** into place.
3. Using item **J** with item **K** loosely bolt item **A** to the existing holes in the rear panel, using the nuts and washers provided loosely bolt item **A** to the captive bolts in item **E**.
4. Locate item **D** through the large holes inside the boot (insert outwardly so that the bolts locate into the holes in the lower face).
5. Loosely bolt item **B** L/H side and item **C** R/H side to the captive nuts using the nuts and washers provided.
6. Using item **G** with item **K** loosely bolt item **C** to item **A** through the existing holes in the chassis.
7. Using item **H** with item **K** loosely bolt item **B** to item **A** through the existing holes in the chassis.
8. Using item **F** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
9. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
10. Replace the spare wheel and the bolt on the underside of the bumper.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

