



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

Type TC700 Mitsubishi Shogun/Pajero '91<

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	8	12 x 25 Washers	E	2	M12 x 120 Bolts, Nuts & S/P Washers
C	2	Exhaust Brackets	F	4	M12 x 35 x 1.25 Bolts & Washers only
			G	1	M8 x 35 Bolt, Nut, S/P Washer & 2 Flat Washers

1. Using item **F** with item **B** under each bolt head loosely bolt item **A** to the existing threaded holes in each chassis member.
2. Using item **E** with item **B** under each bolt head and item **C** on the top face of the chassis bolt item **A** at the rear set of holes.
3. Using item **D** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
4. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
5. It may be necessary to lower the rear exhaust using item **C** and item **G**.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

