



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TC713 Mitsubishi L200 Pick-Up (4 Work) 2006>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	H	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Side Arms	J	2	M12 x 40 Bolts & S/P Washers
C	2	Angle Brackets	K	8	M12 x 40 Bolts & Nyloc Nuts
D	2	Handed Clamp Plates	L	8	M12 Nyloc Nuts
E	1	Coupling Spacer	M	8	M12 Bolt Caps
F	2	Washer with Captive Bolt			
G	2	Clamp Plate With Captive Nut			

1. Remove the two existing nuts securing the underun bar to each chassis member. (This is not refitted with the towbar.)
2. Remove the existing clamp plate with captive bolts and replace with Item D.
3. Locate Item B onto each set of bolts and loosely secure using Item L.
4. Place Item F into each chassis and down through the existing hole, using Item L loosely bolt Item C to the underside of each chassis.
5. Using Item K loosely bolt Item C to Item B.
6. Using Item J and Item K bolt Item A to Item B.
7. Using Item H bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate. Use Item E (coupling spacer) if required.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

