



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TC713A Mitsubishi L200 Pick-Up (With Step) 2006>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	H	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Side Arms	J	2	M12 x 40 Bolts & S/P Washers
C	2	Angle Brackets	K	8	M12 x 40 Bolts & Nyloc Nuts
D	2	Handed Clamp Plates	L	8	M12 Nyloc Nuts
E	1	Coupling Spacer	M	8	M12 Bolt Caps
F	2	Washers with Captive Bolt			
G	2	Clamp Plate With Captive Nut			

1. Remove the three existing nuts securing the bumper step to each chassis member.
2. Remove the existing spacers and clamp plate with captive bolts and replace with Item D.
3. Locate Item B between the bumper irons and the chassis and loosely bolt using Item L.
4. Place Item F into each chassis and down through the existing hole, using Item L loosely bolt Item C to the underside of each chassis.
5. Using Item K loosely bolt Item C to Item B.
6. Using Item J and Item K bolt Item A to Item B.
7. Using Item H bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate. Use Item E (coupling spacer) if required.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

