



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

## TCH1 CHRYSLER CHEROKEE JEEP 2001>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Handed Side Arms	E	6	M12 x 40 Bolts & S/P Washers
C	1	Extension Bar	F	6	M12 x 35 Bolts, 4 Nuts & 6 S/P Washers
			G	2	M12 x 100 Grade 10.9 Bolts & Nyloc Nuts
			H	6	12 x 40 Flat Washers
			J	4	12 x 25 Flat Washers

1. Remove the towing eye. (This is no longer required.)
2. Using Item **E** with Item **H** loosely bolt Item **B** to the existing captive nuts in the lower face of each chassis member.
3. Using Item **F** loosely bolt Item **A** to Item **B**.
4. Using Item **G** with Item **J** bolt Item **C** to Item **A**.
5. Using Item **D** bolt the ball bracket (not supplied in this kit) to the mounting plate.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

**Note:**

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

