



# Tow-Trust Towbars

**Important: Please read General Notes overleaf before fitting**

Issue 1

## TCV1 CHEVROLET Astro Van & Safari NOT 4x4 Series

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	R/H Side Arm	E	4	M14 x 35 Bolts, Nuts & S/P Washers
C	1	L/H Side Arm	F	6	12 x 25 Flat Washers

1. Lower the spare wheel.
2. Locate and remove three fixings each side securing bumper brackets to chassis and retain.
3. Using Item **F** with the existing fixings bolt Item **B** to the right hand chassis and Item **C** to the left hand chassis.
4. Using Item **E** bolt Item **A** to Item **B** Item and Item **C**.
5. Using Item **D** bolt the ball and wiring plate (not supplied in this kit) to Item **A**.
6. Replace the spare wheel.

**Important:** It is very popular for this vehicle to have been modified with some sort of body kit, this is usually fine but a bumper cut will then be required.

**Note:** Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

