



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TD976 Daihatsu Sportrak 89-98

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	B	2	M16 x 50 Bolts, Nuts & S/P Washers
			C	4	M12 x 35 Bolts, Nuts & S/P Washers
			D	4	M10 x 30 x 1.25 Bolts & S/P Washers
			E	4	10 x 30 Flat Washers
			F	4	12 x 40 Flat Washers

1. Remove the towing eye from the centre of the vehicle.
2. Remove the outer bumper bolts from each side.
3. Using item **D**, with item **E** under each bolt head, loosely bolt item **A** into place.
4. Using item **C**, with item **F** under each bolt head, bolt item **A** to the centre towing eye mounting points.
5. Using item **B** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

