



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TF1027 Flat Punto '94>

Item	Qty	Description	Item	Qty	Description
A	1	Rear Plate	E	2	M16 x 50 Bolts, Nuts and Washers
B	1	Bracing Stay	F	9	M10 x 30
C	1	3 Hole Clamp Plate	G	6	10 x 25 Flat Washers
D	2	Clamp Plates			

1. Remove the rear bumper. (Four screws underneath boot lid, four screws underneath the bumper and two screws at each wheel arch).
2. Place tem **A** centrally against the rear panel and up to the floor NOTE item **A** must fit to match the contours of the rear panel.
3. Using the holes in item **A** as a jig, drill four 11mm holes through the rear panel.
4. Place two of item **F** into the two lower holes in tem **A**. Then using item **F** with item **G** and item **D** inside the boot loosely bolt item **A** to the rear panel.
5. Loosely bolt item **B** to item **A**.
6. Centralise item **B**, then using the forward holes as jigs, drill three 11mm holes up into the boot floor.
7. Place item **C** inside the boot over the three holes just drilled and using item **F** bolt item **B** into place.
8. Using item **E** bolt the ball bracket and wiring plate (not supplied n this kit) to the mounting plate.
9. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure. (At this stage prepare the wiring and replace the bumper).

Note: nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

