



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TF108 Ford Granada Saloon MK. I & II 1972 - 1985

Item	Qty	Description	Item	Qty	Description
A	1	Drop Plate	D	1	Clamp Strap
B	1	Angle Bracket	E	2	M16 x 45 Bolts, Nuts & S/P Washers
C	1	Main Bar	F	8	M10 x 30 Bolts, Nuts & S/P Washers

1. Using Item F, bolt Item A to Item B. (See sketch)
2. Remove the split pin from the differential bolt, support the diff and remove the slotted nut. The existing thick washer is not required. Replace the large cup washer onto the diff, bolt the opposite way to the way it came off. Using the slotted nut, loosely bolt Item C to the diff bolt.
3. Using Item E, bolt Item A to Item C. (See sketch)
4. Push the towbar up to the boot floor, centralise, and mark off and drill four 11mm holes. Place Item D over the holes inside the boot and using Item F, bolt the towbar into place.
5. Using Item E, bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure. Replace the split pin.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

