



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TF121A Ford Escort Hatchback 1986 - 1990

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	4	58mm Spacer Tubes
B	2	Clamp Plates	F	4	M16 x 45 Bolts, Nuts & S/P Washers
C	1	Extension Bar	G	4	M10 x 90 Bolts, Nuts & S/P Washers
D	1	Bracing Stay	H	2	M10 x 30 Bolts, Nuts & S/P Washers
			I	1	10 x 40 Flat Washer
			J	4	10 x 25 Flat Washers
			K	2	Bolt caps

1. Remove the spare wheel.
2. On the underside of the chassis, locate the rearmost blanked off existing holes in each chassis member. Knock out the blanks and drill 11mm holes up into the boot. Open the top holes only to 20mm. Using Item **G** with Item **B** inside the boot and Item **E** passed down into the chassis, loosely bolt Item **A** into place.
3. Using the rearmost hole in Item **A** as a jig, drill 11mm hole up into the boot. Open the top hole only out to 20mm. Using Item **G** with Item **E** inside the chassis, bolt Item **A** into place.
4. Using Item **H** bolt item **D** to Item **A** and locate on the underside of the spare wheel well. Using the hole in Item **D** as a jig, drill 11mm hole up into the boot. Using Item **H** with Item **I** inside the boot, bolt Item **D** into place.
5. Using Item **F**, bolt Item **C** to Item **A**.
6. Using item **F** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure. Replace the spare wheel.

Note:

1. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

