



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

## TF133A Granada Scorpio Saloon (With Boot) 90> & Estate 92>

Item	Qty	Description	Item	Qty	Description
A	1	Crossbar	G	1	Small Clamp Plate with Welded Bolt
B	1	Angle Bracket	H	2	M16 x 50 Bolts Nuts & Washers
C	1	Drop Plate	I	2	M10 x 65 .. ..
D	1	Drop Arm Assembly (3 parts)	J	9	M10 x 30 Bolts 12 Nuts 13 Washers
E	1	Bracing Stay	K	4	M8 x 35 Bolts & SP Washers only
F	1	Large Clamp Plate with Welded Bolt	L	2	M10 x 25 Washers

1. Remove the rear bumper (two 8mm bolts each side underneath and one large butterfly each side near the bumper tips) on early models, remove the trim from the underside of the bumper and cut a slot 140mm wide (see sketch below).
2. Pass item **B** through the large hole in the rear box section, locate the middle hole in item **B** with the existing hole in the panel, using item **J** loosely bolt item **C** to item **B**.
3. Pass item **F** down the right hand chassis, and item **G** down the left hand chassis and locate the bolts down in the existing holes, loosely bolt item **A** to these bolts, using the holes in item **A** as jigs drill two 11mm holes up through the floor and through the holes in item **B** using item **J** loosely bolt item **B** to item **A** using item **I** bolt item **C** to item **A**.
4. Remove the two rear bolts securing the differential, and loosely bolt item **D** using the existing bolts, using item **J** bolt the angle part of item **D** to the drop arms.
5. Using item **J** bolt item **E** to item **C** and item **D**.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
7. Refit bumper using item **K** and the existing thick washers and butterflies.
8. Using item **H** bolt the ball bracket and the wiring plate (not supplied in this kit) to the mounting plate.

**Note:** nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

