



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TF 144A Ford Mondeo Estate 93>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	6	M10 x 120 Bolts Nuts & Washers
B	1	L/H Side Arm	H	4	M10 x 30 Bolts Nuts & Washers
C	1	R/H Side Arm	I	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
D	1	Extension Bar	J	6	10 x 30 Flat Washers
E	6	17 x 93 Spacer Tubes	K	4	10 x 25 Flat washers
F	2	M16 x 50 Bolts Nuts & Washers	L	4	12 x 25 Flat Washers

1. Lower the heat shield on the left hand side
2. Locate the three existing holes in each chassis member place item **J** and item **E** under the head of each item **G** make sure the bolts locate in the slots provided
3. Loosely bolt item **B** and item **C** to the inside face of each chassis member
4. Using item **H** with item **K** bolt item **A** to item **B** and item **C**
5. Using item **I** and item **L** bolt item **D** to item **A**
6. Using item **F** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure
8. Replace the heat shield

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

