



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

## Type TF145A Ford Maverick 93> Nissan Terrano II 93>>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	10	M12 x 40 Bolts, Nuts & Washers
B	2	Side Arms	E	8	12 x 25 Flat Washers
C	2	M16 x 50 Bolts, Nuts & Washers			

1. Using Item **D** with Item **E** loosely bolt Item **B** to the existing holes in the chassis brackets each side.
2. Using Item **D** bolt Item **A** to Item **B**.
3. Using item **C** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
4. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

**Note:** nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

