



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TF163 Ford Maverick 01>/Mazda Tribute 01>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	C	2	M16 x 50 Bolts Nuts & Washers
B	1	Handed Side Arms	D	8	M12 x 45 Bolts & Washers
			E	4	M8 Special Nuts
			F	4	12 x 40 Flat Washers
			G	4	10 x 25 Flat Washers
			H	4	12 x 25 Flat Washers

1. Remove the rear bumper. Four screws and two bolts along the top edge, two screws at the tips, two lower mudguard screws and two nuts on the underside of the rear panel. Remove the four nuts securing the bumper beam.
2. Cut the lower edge of the bumper 60mm wide x 60mm deep.
3. Locate item **B** into each chassis member and using item **D** with item **F** loosely bolt to existing holes.
4. Using item **D** with item **H** loosely bolt item **A** to item **B**.
5. Using item **E** with item **G** bolt item **A** to the rear panel.
6. Using item **C** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
8. Replace the bumper.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

