



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TF175 Iveco Cargo (With Under-run Crossbar) 2003>

| Item | Qty | Description | Item | Qty | Description |
|------|-----|------------------|------|-----|-------------------------------------|
| A | 1 | Face Plate | F | 8 | M16 x 40 Bolts and Nyloc Nuts |
| B | 1 | Rear Clamp Plate | G | 2 | M16 x 50 Bolts Nuts and S/P Washers |
| C | 1 | L/H Side Arm | | | |
| D | 1 | R/H Side Arm | | | |
| E | 1 | Coupling Spacer | | | |

1. Using Item F loosely bolt Item A to Item B through the top holes.
2. Locate assembly centrally onto vehicle under-run crossbar and using Item F loosely bolt clamp plate (Item B) to face plate (Item A).
3. Using Item F loosely bolt Item C and Item D to the towbar assembly and to the existing hole in each chassis. (**Note.** If holes in chassis are not existing then use the hole in side arms as a jig and drill 17mm holes through each chassis face).
4. Using Item G bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

NOTE: Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

