



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TFD 1 VKF FORD FIESTA 2008>

| Item | Qty | Description | Item | Qty | Description |
|------|-----|------------------------|------|-----|--|
| A | 1 | Crossmember | F | 8 | M10 x 40 Bolts, 2 Nuts & 8 Washers |
| B | 1 | Right Hand Side Arm | G | 2 | M12 x 22 Bolts & Washers |
| C | 1 | Left Hand Side Arm | H | 2 | M12 x 25 Bolts & Washers |
| D | 1 | Detachable Housing | J | 8 | 12 x 25 Flat Washers |
| E | 1 | Flip Down Socket Plate | K | 4 | 10 x 30 Flat Washers |
| | | | L | 2 | M12 x 85 Grade 10.9 Bolts & Nyloc Nuts |
| | | | M | 2 | M16 x 40 Bolts, Nuts & S/P Washers |
| | | | N | 1 | Extension Bar |

1. Remove the rear bumper.
2. Remove the bumper impact beam (This is not refitted with the Towbar) replace nuts back onto the studs.
3. Locate item **B** into the right hand chassis and loosely bolt in place using item **F** with item **K**.
4. Locate item **C** into the left hand chassis and loosely bolt in place using item **F** with item **K**.
5. Using item **F** bolt item **A** between item **B** and item **C**.
6. Using item **G** with item **J** and item **H** with item **J** bolt item **D** and item **E** to item **A**.
7. Fully tighten all nuts and bolt and ensure Towbar is rigid and secure.
8. Cut the bumper **SEE SKETCH**.
9. Refit the bumper.
10. Locate Detachable Neck into its receptor and lock in position, using item **L** with item **J** bolt item **N** to the detachable neck assembly.
11. Using item **M** bolt the ball bracket (not supplied in this kit) to item **N**.
12. Fully tighten all remaining bolts.

Note: nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

