



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TFD 2VK FORD KUGA 2008

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	1	Flip Down Socket Plate
B	2	Handed Side Arms	E	10	M10 x 35 Bolts, 4 Nuts & 10 Washers
C	1	Detachable Housing	F	2	M12 x 22 Bolts & Washers
			G	2	M12 x 25 Bolts & Washers
			H	4	12 x 25 Flat Washers
			J	4	10 x 40 Flat Washers

1. Remove the rear bumper, one fixing either side of boot opening, four fixings along lower edge of bumper, three fixings around wheel arch, fold back wheel arch liner to reveal one remaining fixing, unplug the fog lights. Bumper tips will need to be pulled out sideways and then rearwards.
 2. Remove the bumper impact beam and towing eye. (impact beam is not refitted with Towbar)
 3. Insert items **B** into the correct chassis and using item **E** and item **J** loosely bolt in place.
 4. Using original fixings re-fit the towing eye to the vehicle and fully tighten.
 5. Using item **E** bolt item **A** between items **B**.
 6. Using item **F** with **H** and item **G** with **H** bolt item **C** with item **D** to item **A**.
 7. Fully tighten all nuts and bolts and ensure Towbar is rigid and secure.
 8. Cut the bumper centrally on the lower face SEE SKETCH (Trim to suit if required) and refit.
- NOTE:** Nose load limits and vehicle manufacturer's weight limits must be observed.

