



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TH251 Honda Accord October 98>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	F	2	M10 x 100 Bolts, Nuts & Washers
B	2	Side Straps	G	2	M10 x 110 Bolts, Nuts & Washers
C	2	17 x 69 Spacer Tubes	H	2	M10 x 30 Bolts, Nuts & Washers
D	2	17 x 74 Spacer Tubes	J	6	10 X 40 Flat Washers
E	2	M16 x 50 Bolts, Nuts & Washers	K	8	10 x 30 Flat Washers
			L	2	10 x 25 Flat Washers

1. Remove the rear bumper (2 plastic fixings along the top edge, 2 screws at the bumper tips and 2 fixings in the wheel arch). Remove the steel bumper crossbeam and retain nuts.
2. Cut a small hole centrally in the bottom edge of the bumper 50mm wide and up to the first ridge.
3. Remove the grommets over the chassis at the forward mounting points, using item **G** with item **J** and item **D** pass down through the existing holes, using the existing rear holes in the chassis as a jig drill up through the boot floor 11mm **open top holes only to 18mm**.
4. Place one of item **K** over each existing stud on the rear panel remove the two rubber grommets, using item **H** with item **J**, item **L** and the existing nuts, loosely bolt item **A** into place.
5. Using item **F** with item **J**, item **K** and item **C** pass down through the rear fixing points in the chassis and bolt item **B** into place using the nuts and washers provided.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
7. Replace the bumper.
8. Using item **E** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

