



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TH253 Honda HR - V 3 & 5 Door 2002>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	4	M16 x 50 Bolts, Nuts & Washers
B	2	Handed Angle Brackets	F	10	M12 x 30 Bolts, 6 Nuts & 10 Washers
C	2	Captive Clamp Straps	G	6	M16 Bolt Caps
D	2	Handed Brackets	H	2	Blanking Grommets

1. Remove the rear bumper, eight fixings along the lower edge, six fixings along the top edge, two tip screws and four fixings securing the mud guards in each wheel arch.
2. Remove the plastic under trim, two plugs in each mud guard, one forward plug on the right hand side and two forward fixings on the left hand side.
3. Locate the existing towing eye slot and enlarge (see sketch).
4. Remove the metal cans each side from the rear panel (these are not refitted), enlarge the existing hole to 30mm.
5. Locate Item C through the 30mm hole into each chassis member.
6. Using Item F loosely bolt Item B to the underside of each chassis.
7. Using Item F loosely bolt Item A to Item B.
8. Using Item E loosely bolt Item A to the vehicle towing eye.
9. Using Item F loosely bolt Item D to Item B and to the existing stud on the rear panel using the original nuts.
10. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
11. Using Item H blank off the 30mm holes in the rear panel.
12. Replace rear bumper and plastic under trim.
13. Using Item E bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

