



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TI950 Isuzi Trooper '92> / Vauxhall Monterey 92>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	C	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Clamp Plates	D	4	M12 x 35 Bolts & S/P Washers
			E	4	12 x 38 Flat Washers

1. Remove the rear bumper. Locate the four existing holes on the inside face of the rear crossmember. Remove the plastic clip from between these holes.
2. Remove the towing hook from the right hand chassis member. Remove the bolts securing the bumper irons.
3. Using the existing bumper mounting bolts, loosely bolt item **A** and, at the same time, bolt the bumper irons back into place. (NOTE: Check these bolts at regular intervals to ensure they have not worked loose.)
4. Using item **D** with Item **E** under each bolt head, and Item **B** placed inside the rear crossmember box section, bolt the towbar into place.
5. Using item **C** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
6. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

