



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TI952 ISUZI 2WD/4WD PICK UP 02> BEDFORD BRAVA 2WD/4WD PICK UP 89>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	F	2	M16 x 50 Bolts Nuts & Washers
B	2	Side Arms	G	15	M12 x 35 Bolts & 13 Nyloc Nuts
C	2	Angle Brackets	H	6	12 x 40 Flat Washers
D	1	Fog Light Bracket			
E	1	Coupling Spacer			

1. Temporarily remove the fog light. Remove fog light from the existing bracket.
2. Using Item G with Item H loosely bolt Item B to the existing holes in the side of each chassis member.
3. Using Item G loosely bolt Item A to Item B.
4. Using Item G loosely bolt Item C to Item B.
5. Using the holes in Item C as a jig, drill 13mm holes up into each chassis member.
6. Using Item G with Item H bolt item C into place.
7. Using Item F with Item E bolt the ball bracket and wiring plate (not supplied with this kit) to the mounting plate.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

