



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TK1 KIA SORENTO 2003>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	E	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	1 L/H Side Arm	F	11	M12 x 35 x 1.5 Bolts, 4 Nuts & 11 S/P Washers
C	1	1 R/H Side Arm	G	1	M12 x 30 x 1.5 Bolt & S/P Washer
D	1	Coupling Spacer	H	16	12 x 25 Flat Washers
			J	1	Exhaust Rubber

1. Remove rearmost exhaust rubber.
- 1A. Temporarily lower the spare wheel.
- 1B. To gain better clearance for item **A** it may be necessary to trim the lower corner of the right side lower bumper tag.
2. Using item **F** (and item **G** on the right hand side) with item **H** loosely bolt item **A** to the existing mounting points in each chassis member.
3. Using item **F** with item **H** loosely bolt item **B** and item **C** to the existing mounting points in each chassis member.
4. Using item **F** with item **H** bolt item **B** and item **C** to item **A**.
5. Using item **E** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
6. Push item **A** upwards and rearwards and fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
7. Raise spare wheel.
8. Refit exhaust using replacement exhaust rubber (Item **J**).

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

