



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

## TK10 Kia Cee'd 2007>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Handed Side Arms	F	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	Extension Bar	G	8	M10 x 35 Bolts, 6 Nuts & 8 S/P Washers
D	2	Angle Brackets	H	6	M10 x 40 x 1.25 Bolts & S/P Washers
			J	10	10 x 25 Flat Washers
			K	4	12 x 25 Flat Washers

1. Locate towbar mounting points and remove any mastic from around them.
2. Using Item **H** with Item **J** loosely bolt the two angle brackets (Item **D**) to the bottom face of each chassis.
3. Using Item **H** with Item **J** loosely bolt the handed side arms (Item **B**) to the outside face of each chassis, noting the correct arm for the correct side (see sketch).
4. Using Item **G**, bolt Item **B** and Item **D** together but do not fully tighten at this stage.
5. Using Item **G** with Item **J**, bolt Item **A** between the handed side arms (Items **B**).
6. Using Item **F** with Item **K**, bolt the extension bar (Item **C**) to Item **A**.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid, square and secure.
8. Ensure there is good clearance around the exhaust and Item **A**, and if needed, adjust the exhaust hanger to suit.
9. Using Item **E**, bolt the ball bracket and wiring plate (not supplied in kit) to mounting plate, and fully tighten.

### Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

