



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 5

TK3 KIA SPORTAGE 2 2004> & HYUNDAI TUCSON 2006 >

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Angle Brackets	E	12	M10 x 40 x 1.25 Bolts, 4 Nuts & 12 S/P Washers
C	1	Extension Bar	F	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
			G	12	10 x 25 Flat Washers
			H	4	12 x 25 Flat Washers
			J	1	Socket Plate

1. Temporarily remove the lower edge of the bumper.
2. Support the exhaust and temporarily remove the three rear exhaust rubbers.
3. Remove the towing eye from the right hand chassis member. (This is not refitted with the towbar.)
4. Locate and remove the tape covering the towbar mounting points.
5. Using item E with item G loosely bolt item B to the outside face of each chassis member.
6. Locate the towbar over the exhaust hanger on the left hand side and using item E with item G loosely bolt to the underside of each chassis member.
7. Using item E with item G bolt item A to item B.
8. Using item F with item H bolt item C to item A (see hole configuration in assembly below)
9. Using item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
10. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
11. Refit exhaust rubbers and lower edge of bumper.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf).
2. Nose load limits and vehicle manufacturers' trailer / caravan weight limits must be observed.

