



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TK9 KIA SORENTO 2006>

| Item | Qty | Description | Item | Qty | Description |
|------|-----|-----------------|------|-----|------------------------------------|
| A | 1 | Towbar | E | 2 | M16 x 50 Bolts, Nuts & S/P Washers |
| B | 1 | L/H Side Arm | F | 6 | M12 x 35 x 1.5 Bolts & S/P Washers |
| C | 1 | R/H Side Arm | F1 | 2 | M12 x 30 x 1.5 Bolts & S/P Washers |
| D | 1 | Coupling Spacer | G | 4 | M12 x 40 Bolts, Nuts & S/P Washers |
| | | | H | 16 | 12 x 25 Flat Washers |
| | | | J | 1 | Exhaust Rubber |

1. Lower the spare wheel
2. Remove the rearmost exhaust rubber.
3. Using Item F with Item H and Item F1 with Item H loosely bolt Item A to the existing mounting points in the inner face of each chassis member.
4. Using Item F with Item H loosely bolt Item B and Item C to the existing mounting points in the outer face of each chassis member.
5. Using Item G with Item H bolt Item B and Item C to Item A.
6. Using Item E bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate. (A coupling Spacer (Item D) is supplied if required.)
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
8. Refit exhaust using replacement exhaust rubber (Item J).
9. Replace the spare wheel.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

