



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

TL242 Layland/DAF 300 & 400 / Sherpa Van & Chassis Cab '83 – (Not Tipper)

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Plate Side Arms	E	6	M12 x 40 Bolts, 4 Nuts & 6 S/P Washers
C	8	17 x 48 Tubes	F	8	M10 x 80 Bolts, Nuts & S/P Washers
			G	8	10 x 40 Washers
			H	10	12 x 25 Flat Washers

1. Remove the towing eye (some models do not have one fitted).
2. Using item **F** with item **C** inside the chassis (some models do not require spacer tubes) and item **G** on the outer face, loosely bolt items **B** to the inside face of each chassis member.
3. Using item **E**, with item **H** bolt item **A** to items **B**.
4. Using item **D** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

