



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

Type TL247 Land Rover Discovery November 98>

Item	Qty	Description	Item	Qty	Description
A	1	Drop plate	E	2	M16 x 65 Bolts, nuts & washers
B	2	Side arms	F	4	M16 x 50 Bolts, nuts & washers
C	1	10mm coupling spacer	G	2	M16 x 110 Bolts nuts & washers
D	1	Drop Plate	H	2	M14 x 90 Bolts & washers
			J	4	16mm Bolt Caps
			K	8	16 x 30 Flat Washers
			L	2	14 x 28 Flat Washers

1. Using item **H** with item **L** loosely bolt item **A** to the rear crossmember.
2. Using item **G** with item **K** loosely bolt item **B** to the existing holes in the chassis.
3. Using item **E** and item **K** with item **C** bolt item **B** and the ball bracket and wiring plate (not supplied in this kit) to item **A**.
4. Fully tighten all nuts and bolts and ensure the Towbar is rigid and secure.
5. Using item **E** and item **F** with item **K** bolt item **D** to item **A** if a lower towing height is required.

This Towbar has been tested to 94/20 EC using a A50-1 dimension Towball, a 75mm drop plate and a 52mm spacer mounted on the lower holes, so that spacers and drop plates up to those limits can be used.

Note: nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

