



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TL257 Land Rover Defender 110 (TD5 Models Only) 1999>

Item	Qty	Description	Item	Qty	Description
A	1	Drop plate	E	2	M16 x 65 Bolts, Nuts & S/P Washers
B	2	Side arms	F	2	M16 x 50 Bolts, Nuts & S/P Washers
C	1	Angle Bracket	G	2	M16 x 40 Bolts Nuts & S/P Washers
D	1	Coupling Spacer	H	3	M10 x 30 Bolts & S/P Washers
			J	2	M12 x 40 Bolts & Nyloc Nuts
			K	3	10 x 20 Flat Washers
			L	4	16 x 30 Flat Washers
			M	4	12 x 25 Flat Washers
			N	4	M12 Plastic Caps

1. Using Item H with Item K loosely bolt Item C to the existing holes in the vehicle crossmember.
2. Using Item G with Item L loosely bolt Item A to the crossmember.
3. Using Item J with Item M bolt Item A to Item C.
4. Using Item F with Item L loosely bolt Item B to Item A.
5. Remove the towing eyes and using the original bolts, bolt the side arms (Item B) to the chassis, at the same time refitting the towing eyes.
6. Using Item E with Item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

