



# Tow-Trust Towbars

**Important:**

**Please Read General Notes (overleaf) Before Fitting:**

Issue 1

## TM6 Mercedes Sprinter Van SWB (With Step) / VW Crafter (With Step) 2006>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Side Arms	E	8	M12 x 130 Grade 10.9 Bolts & Nyloc Nuts & 4 S/P Washers
C	1	Coupling Spacer	F	6	M12 x 40 Bolts Grade 10.9 & 4 Nyloc Nuts & 2 S/P Washers
			G	12	12 x 25 Flat Washers

1. Remove the four bolts each side securing the step brackets to the chassis.
2. Using Item **E** with Item **G** loosely bolt Items **B** to the outer face of each chassis member.
3. Using Item **F** with Item **G** bolt Item **A** to Item **B**.
4. Using Item **D** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate. Note: Coupling spacer (Item **C**) is provided if required.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

**Note:** nose load limits and vehicle manufacturers' trailer / caravan weight limits must be observed.

