



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TM865 Mercedes Sprinter Chassis Cab1994> & Volkswagen LT Chassis Cab RWD 1996>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Side Arms	E	8	M12 x 90 Bolts & Nyloc Nuts
C	1	Coupling Spacer	F	6	M12 x 35 Bolts & 4 Nyloc Nuts
			G	24	12 x 25 Flat Washers

1. Using Item E with Item G loosely bolt Item B to the existing holes in each chassis member.
2. Using Item F with Item G bolt Item A to Item B.
3. Using Item D with Item C bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
4. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note:

1. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

