



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

## TM876 Mercedes 'A' Class 1998>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	C	2	M16 x 50 Bolts Nuts & S/P Washers
B	2	Clamp Plates	D	4	M10 x 35 Bolts & S/P Washers
			E	4	10 x 25 Flat Washers

1. Cut bumper 50 x 100. (See Sketch) If required trim to suit.
2. Temporarily remove the rear exhaust bracket.
3. Locate item B through the access holes on underside of each chassis and over the existing holes.
4. Using item D with item E bolt item A into place.
5. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure and the face plate is vertical.
6. Trim the plastic under tray if it touches the towbar.
7. Re-fit exhaust bracket and bumper.
8. Using item C bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.

**Note:** nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

