



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TM879 Mercedes Vito/Viano 2003>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	C	2	M16 x 50 Bolts, Nuts & Washers
B	1	Clamp Plate	D	6	M12 x 100 Bolts & Nyloc Nuts
			E	4	12 x 40 Flat washers
			F	8	12 x 25 Flat Washers

1. Remove the towing eye on the right hand side.
2. On the left hand side remove the two plastic grommets from the mounting points.
3. Using Item E with Item H and Item G loosely bolt Item A to the existing holes in each chassis.
4. Using Item F with Item J loosely bolt Item B to Item A and to the rear crossmember.
5. Using item D with Item C bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
6. Ensure towball mounting plate is vertical, then fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

