



Tow-Trust Towbars

Important:

Please Read General Notes (overleaf) Before Fitting:

Issue 1

TMZ168 MAZDA BONGO CAMPER (IMPORT)>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	F	2	M16 x 50 Bolts, Nuts & Washers
B	1	L/H Side Plate	G	1	M10 x 110 Bolt, Nut & Washer
C	1	Clamp Plate	H	2	M12 x 35 Bolts, Nuts & Washers
D	1	19 x 76 Spacer Bush	J	3	M10 x 35 Bolts & Washers Only
E	1	2 hole Clamp Plate	K	3	M10 x 30 x 1.25 Bolts & Washers Only
			L	1	10 x 30 Flat Washer
			M	7	10 x 25 Flat Washers
			N	2	12 x 25 Flat Washer

1. Remove the towing eye from the offside chassis.
2. Remove the rear trim from inside the boot.
3. Locate Item **E** into the box section on the near side and using Item **J** with Item **M** loosely bolt Item **B** through the existing holes.
4. Using Item **K** with Item **M** loosely bolt Item **A** to the existing captive nuts on the offside chassis.
5. Using Item **H** with Item **N** loosely bolt Item **A** to Item **B**.
6. Locate Item **C** into the offside chassis and using Item **J** with Item **M** bolt Item **A** into place.
7. Using the hole in Item **A** as a jig, drill an 11mm hole up into the boot, open the top hole only to 20mm. Place Item **D** down into the hole and bolt using Item **G** with Item **L**.
8. Using Item **F** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
9. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

