



# Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

## TMZ4 MAZDA 6 2008>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts Nuts & Washers
B	2	Handed Side Arms	E	4	M12 x 45 Bolts & 4 Washers
C	1	Extension bar	F	4	M12 x 35 Bolts, 2 Nuts & 4 Washers
			G	1	M12 x 100 Grade 10.9 Bolt & Nyloc Nut
			H	2	M12 x 40 Grade 10.9 Bolts & Washers
			J	4	12 x 40 Flat Washers
			K	4	12 x 25 Flat Washers

1. Remove the rear light clusters, 3 fixings inside the boot, ease the light backward to release the clip.
2. Remove the rear bumper, fixings along lower edge, one fixing on lower wheel arch, one tip fixing and one fixing beneath each light cluster. (ESTATE ONLY: Two fixings on boot shut panels).
3. Lower the rear exhaust silencer and support to prevent any damage. (V6 MODEL Lower both silencers).
4. Remove the bumper beam. (This is not refitted with the Towbar).
5. Cut the exhaust hangers from the bumper beam as shown (See sketch).
6. Locate Towbar mounting points and clear of any tape or mastic.
7. Using original fixings bolt the exhaust hangers back on the rear panel.
8. Using item E with item J loosely bolt items B into each chassis.
9. Using item F bolt item A between side arm B.
10. Using items G with item K and items H with items K bolt item C to item A.
11. Fully tighten all nuts and bolts and ensure Towbar is rigid and secure.
12. Re hang the exhaust silencers onto original hangers.
13. Cut the bumper centrally 85 wide x 85 deep and refit.
14. Using items D bolt the ball bracket and wiring plate (not supplied in this kit) to the face plate and fully tighten.

**Note:** nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

