



Tow-Trust Towbars

Important:

Please Read General Notes (overleaf) Before Fitting:

Issue 3

Type TN5 NISSAN QASHQAI 2007>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	L/H Side Plate	H	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	R/H Side Plate	J	4	M10 x 40 Bolts & S/P Washers
D	1	L/H Clamp Bracket	K	8	M12 x 40 Bolts, 2 Nuts & 8 S/P Washers
E	1	R/H Clamp Strap	L	4	10 x 30 Flat Washer
E1	1	R/H Clamp Strap	M	8	12 x 25 Flat Washers
F	1	Extension Bar	N	1	L/H Socket Plate

1. Remove rear bumper. Six fixings along lower edge, two fixings from top edge, remove wheel arch trims to reveal three fixings and one tip fixing each side. Pull bumper out at each side then pull rearwards. Temporarily disconnect fog lamps and reversing sensors.
2. Remove the three bolts securing each end cap from the rear of each chassis.
3. Locate Item **D** into left hand chassis and over the four existing mounting holes, using Item **K** with Item **M** loosely bolt Item **B** into place.
4. Using Item **J** with Item **L** loosely bolt Item **C** to the right hand chassis with Item **E** and Item **E1** located inside the chassis.
5. Using Item **K** bolt Item **A** to Item **B** and Item **C**.
6. Refit chassis end caps with original nuts.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
8. It may be necessary on some models to trim the black plastic shield from the nearside under the vehicle around where Item **B** bolts.
9. Refit reversing sensors, fog light and rear bumper.
10. Using Item **H** with Item **M** bolt Item **F** and Item **N** to Item **A**.
11. Using item **G** bolt the ball bracket (not supplied in this kit) to the mounting plate.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

