



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TN828 Nissan Patrol GR (Y61)

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	E	2	M16 x 50 Bolts, Nuts & Washers
B	2	Spacer Plates	F	6	M12 x 140 Bolts, Nuts & Washers
C	6	19 x 87 Spacer Tubes	G	6	12 x 25 Flat Washers
D	1	50 x 10 x 130 Spacer	H	6	12 x 40 Flat Washers

- 1.** Remove the rear bumper. Three bolts along the lower edge, one in the mud guard, four fixings in the mud flap edges, one plastic plug in the corner and one screw on the top edge. Temporarily disconnect the wiring loom.
- 2.** Remove the inner bumper beam, four bolts in the central towing eye and four bolts in the ends of each chassis.
- 3.** Locate item **C** into the ends of each chassis over the two existing forward holes.
- 4.** Using item **F**, item **G**, item **H** and item **B** between the towbar and the chassis loosely bolt into place the forward two holes.
- 5.** Using the rearmost hole in item **A** as a jig, drill 13mm hole up through the chassis. Bolt into place using item **F**, item **G** and item **H**. (Place this bolt in from the top so that the bolt does not foul the bumper).
- 6.** Using item **E** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
- 7.** Fully tighten all nuts and bolts and ensure the towbar is rigid and secure. Replace bumper and wiring loom.

Note: nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

