



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

TN829 Nissan Vanette / Serena Cargo '95>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	E	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Handed Side Angles	F	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts
C	1	Extension Bar	G	22	M10 x 30 x 1.25 Bolts, 4 Nuts & 22 S/P Washers
D	2	15 x 20 Spacer Tubes	H	2	M8 x 35 Bolts & S/P Washers Only
			J	22	10 x 25 Flat Washers
			K	4	12 x 25 Flat Washers
			L	2	8 x 20 Flat Washers

- 1.** On some models temporarily remove the rear exhaust mounting bracket. On re-fitting use item **H**, item **L** and item **D** and reverse the bracket to give more clearance.
- 2.** Using item **G** with item **J** loosely bolt item **A** to the existing threaded holes in the rear panel.
- 3.** Using item **G** with item **J** loosely bolt item **B** to the existing threaded holes in each chassis member.
- 4.** Using item **G** with item **J** bolt item **B** to item **A**.
- 5.** Using item **F** with item **K** bolt item **C** to item **A**.
- 6.** Using item **E** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
- 7.** Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

