



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TN 834 NISSAN CABSTAR 1999> RENAULT MAXITY 2007>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	D	2	M16 x 50 Bolts Nuts & Washers
B	2	Side Arms	E	18	M10 x 35 Bolts & Nyloc Nuts
C	1	Coupling spacer	F	4	M12 x 35 Bolts, Nuts & Washers
			G	4	10 x 25 Flat Washers
			H	2	Angle Brackets

1. Remove the two bolts securing the lighting board to the left hand chassis bracket, remove the mounting bracket from the chassis (this is no longer required).
2. Using item E and the original washers loosely bolt item B to the left hand chassis.
3. Using item E and item G loosely bolt item H to the lighting board and item B.
NOTE: It may be necessary to adapt the original lighting board brackets and not use items H.
4. Repeat above instructions for the right hand side.
5. Using item F bolt item A to item B.
6. Using item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

