



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 5

Type TP423 Peugeot 406 Estate 97>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	2	M16 x 50 Bolts Nuts & Washers
B	1	Extension Bar	H	2	M12 x 85 Bolts & Nyloc Nuts
C	1	L/H Side Arm	I	4	M10 x 35 Bolts & S/P Washers
D	1	R/H Side Arm	J	4	M10 x 35 Bolts 2 Nuts & 4 S/P Washers
E	4	M10 Caged Nuts	K	2	M12 x 40 Bolts & S/P Washers
E1	2	M12 Caged Nuts	L	4	10 x 30 Flat Washers
F	2	Spacer Blocks	M	6	12 x 25 Flat Washers
			N	1	Socket Plate

1. Remove the two rear rubber mountings from the exhaust, remove the heat shield.
2. Locate the two square holes in each chassis member and insert item **E** into place.
3. Using item **I** with item **L** under each bolt head loosely bolt item **C** and item **D** into place.
4. Using item **J** loosely bolt item **A** to item **C** and item **D**.
5. Using item **K** with item **F** and item **M** under each bolt head loosely bolt item **A** to the existing threaded holes in the rear panel (these holes may be covered with tape) (if not existing insert item **E1**).
6. Using item **H** with item **M** bolt item **B** to item **A**.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
8. Replace the heat shield and rubber mountings onto the exhaust.

Note: nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

