



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

Type TP5 Fiat Scudo / Citroen Dispatch / Peugeot Expert 2007>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	E	2	M16 x 50 Bolts Nuts & S/P Washers
B	1	L/H Side Arm	F	2	M12 x 110 Bolts & Nyloc Nuts
C	1	R/H Side Arm	G	7	M12 x 40 Bolts 5 Nuts & 7 S/P Washers
D	2	22 x 67 Spacer Bushes	H	1	M10 x 40 Bolt & S/P Washer
			J	1	Captive Clamp Plate M10
			K	3	12 x 40 Flat Washers
			L	1	10 x 30 Flat Washers
			M	1	Coupling Spacer
			N	1	Captive Clamp Plate M12

1. Lower spare wheel and unclip carrier.
2. Using item F with item K loosely bolt item B and item C to the inside face of each chassis member. Locate item D into each existing hole on the outer face of each chassis member.
3. Using item G with item K and item N bolt the left hand side arm (item B) to the existing forward hole in the bottom face of the forward crossmember.
4. Locate item J through the rectangular hole in the bottom face of the right hand chassis and using item H with item L bolt item C into place at the forward hole.
5. Using item G bolt item A to item B and item C.
6. Using item E bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate. Note: A coupling spacer is supplied if required.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
8. Replace spare wheel.

Note: nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

