



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 1

TR 6 RENAULT KANGOO II 2009>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	L/H Side Arm	E	4	M10 x 40 Bolts & S/P Washers
C	1	R/H Side Arm	F	2	M8 x 40 Bolts & S/P Washers
			G	4	M12 x 35 Bolts, Nuts & S/P Washers
			H	4	10 x 25 Flat Washers
			J	2	8 x 25 Flat Washers

1. Lower the spare wheel, remove the four lower fixings from the bottom edge of the bumper.
2. Remove the two fixings securing exhaust bracket to chassis and discard fixings.
3. Using items **E** and items **H** loosely bolt items **B** and **C** to the correct chassis. Note: Item **C** gets sandwiched between the chassis and the exhaust bracket.
4. Using item **F** and **J** loosely bolt items **B** and **C** to the remaining forward Towbar mounting points.
5. Using item **G** bolt item **A** to the side arms.
6. Using item **D** bolt the ball bracket and wiring plate (Not supplied in this kit) to item **A**.
7. Fully tighten all nuts and bolts ensuring Towbar is rigid and secure.

Note: Nose load limits and vehicle manufacturer's trailer / caravan weight limits must be observed.

