



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TR820 Renault Megane 5 Door Hatchback '96>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	J	1	M10 x 100 Bolt & S/P Washers only
B	1	Extension Bar	K	2	M8 x 25 Bolt & S/P Washers only
C	2	Angle Brackets	L	2	M10 x 35 Bolts, Nuts & Washers
D	1	R/H Side Arm	M	4	M12 x 35 Bolts, 2 Nuts & 4 Washers
E	1	L/H Side Arm	N	2	10 x 40 Flat Washers
F	2	17 x 54 Spacer Tubes	P	2	8 x 25 Flat Washers
G	2	M8 Caged Nuts (Steel & Plastic)	R	2	10 x 25 Flat Washers
H	2	M16 x 50 Bolts, Nuts & Washers	S	4	12 x 25 Flat Washers
I	1	M10 x 110 Bolt & Washer only	T	2	M12 x 85 Grade 10.9 Bolts & Nyloc Nuts

1. Locate the existing forward mounting holes in each chassis. Place item **F** into each hole and using item **I** with item **N** loosely bolt item **E** to the left hand side and using item **J** with item **N** loosely bolt item **D** into place on the right side.
2. Remove the plastic grommets (or tape) from the upper two holes in the rear panel. Locate item **G** (steel or plastic depending on the shape of the hole) into the upper hole each side.
3. Using item **K** with item **P** loosely bolt item **C** to the caged nuts.
4. Using item **L** with item **R** loosely bolt item **A** to item **C** and through the existing lower hole in the rear panel.
5. Using item **M** bolt item **D** and item **E** to item **A**.
6. Using item **T** with item **S** bolt item **B** to item **A**.
7. Using item **H** bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
8. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note:

1. Recommended Torque Setting for M12 Grade 10.9 -139 Nm. (For other Torque Settings see notes overleaf.)
2. Nose load limits and vehicle manufacturers trailer / caravan weight limits must be observed.

