



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 2

TR821 Renault Megane Scenic '96>

Item	Qty	Description	Item	Qty	Description
A	1	Crossmember	G	2	M16 x 50 Bolts, Nuts & S/P Washers
B	2	Angle Brackets	H	1	M10 x 100 Bolt & S/P Washer
C	1	R/H Side Arm	J	1	M10 x 110 Bolt & S/P Washer
D	1	L/H Side Arm	K	2	M8 x 25 Bolts & S/P Washers
E	2	17 x 54 Spacer Tubes	L	6	M10 x 35 Bolts, 5 Nuts & 6 S/P Washers
F	2	M8 Caged Nuts (Steel or plastic)	M	2	10 x 40 Flat Washers
			N	2	8 x 25 Flat Washers
			P	6	10 x 25 Flat Washers

1. Locate the two holes each side in the rear crossmember of the vehicle. Note: The upper holes each side either have tape covering them or have plastic bungs in them and both are covered with mastic.
2. Remove plastic bungs or tape from the upper two holes.
3. Locate either the steel caged nuts into the existing oblong hole or the plastic bayonet nut into the shaped holes. (See sketch.)
4. Using item K with item N loosely bolt item B to the caged or bayonet nuts. Note: The bottom holes in item B should now line up with the bottom existing holes in the rear panel.
5. Locate the forward mounting hole in the R/H chassis, using item H with item M under the bolt head and item E over the bolt, pass through the existing hole and loosely bolt item C into place.
6. Locate the forward mounting hole in the L/H chassis, using item J with item M under the bolt head and item E over the bolt, pass through the existing hole and loosely bolt item D into place.
7. Using item L with item P loosely bolt item A to item B and through the existing hole in the rear panel.
8. Using item L with item P bolt item C and item D to item A.
9. Using item G bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate.
10. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufacturers' trailer / caravan weight limits must be observed.

