



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 4

TR 822 Renault Master Van '98> Vauxhall Movano '98> Nissan Interstar 98>

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	D	2	M16 x 50 Bolts, Nuts & S/P Washers
B	1	Coupling Spacer	E	4	M10 x 45 Bolts & S/P Washers
C	2	Handed Side Arms	F	5	M8 x 35 Bolts & S/P Washers
			G	8	M12 x 40 Bolts, 2 Nuts & 8 S/P Washers
			H	5	8 x 25 Flat Washers
			J	4	10 x 30 Flat Washers
			K	8	12 x 25 Flat Washers

1. Remove the three bumper arms (these are no longer required).
2. Remove the two inner bolts securing the towing eye to the chassis.
3. Using Item E with Item J loosely bolt Item A to the existing threaded holes in the side of each chassis.
4. Using Item F with Item H bolt the bumper at existing points to Item A.
5. Using Item G with Item K loosely bolt Item C to the existing holes in the bottom face of each chassis and to the two holes in Item A.
6. Using Item D bolt the ball bracket and wiring plate (not supplied in this kit) to the mounting plate. Item B coupling spacer is supplied if required.
7. Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.

Note: nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

