



Tow-Trust Towbars

Important: Please read General Notes overleaf before fitting

Issue 3

TR823 Renault Espace / Grand Espace 97-

Item	Qty	Description	Item	Qty	Description
A	1	Towbar	E	2	M16 x 100 bolts, nuts & washers
B	2	M12 clamp plates	F	2	M12 x 140 bolts, sq nuts & washers
C	2	19 x 106 tubes	G	4	M12 x 35 bolts, 2 nuts & 4 washers
D	1	50mm spacer block	H	8	12 x 40 flat washers

- 1.** Remove the cover from the centre of the bumper and lower the spare wheel. (retain the cover in case towbar is removed).
- 2.** Locate the M12 square nuts into position, corresponding with item F, bend the small tab to hold the nuts in place.
- 3.** Locate item A into position and using item G, with item H, loosely bolt the towbar through the existing holes at each side.
- 4.** Using item G with item H and item B passed through the apertures and over the existing holes, loosely secure the towbar at these points.
- 5.** Using item F and item C secure the towbar to the square nuts already in position.
- 6.** Using the holes in item A as a jig, drill two 17mm holes through the rear panel (these holes will break into the existing holes with no detriment to the strength of the towbar).
- 7.** Using item E with item D bolt the ball bracket and wiring plate (not supplied in this kit) into position.
- 8.** Fully tighten all nuts and bolts and ensure the towbar is rigid and secure.
- 9.** Replace the spare wheel.

Note: nose load limits and vehicle manufactures trailer / caravan weight limits must be observed.

